





How to switch single +12V rail and multiple +12V rails?



[OFF] for single +12V rail



[ON] for Multiple +12V rails

Note:

1. This power supply's default setting is six +12V rail configuration
2. Turn the switch on for six +12V rails and off for single +12V rail
3. Please make sure to turn off the power supply before adjusting the switch