

한국어

- A. 알루미늄 케이스
- B. 인쇄회로기판(PCB)
- C. 스크류 드라이버
- D. 나사
- E. USB 3.0 케이블

ENGLISH

- A. Aluminum case
- B. Circuit board (PCB)
- C. Screwdriver
- D. Screw
- E. USB 3.0 cable

DEUTSCH

- A. Aluminiumgehäuse
- B. Platine (PCB)
- C. Schraubendreher
- D. Schrauben
- E. USB 3.0-Kabel

日本語

- A. アルミニウム製ケース
- B. プリント基板(PCB)
- C. ドライバーをねじ
- D. ネジ
- E. USB 3.0ケーブル

ESPAÑOL

- A. Carcasa de aluminio
- B. Placa de circuito integrado (PCB)
- C. Destornillador
- D. Tornillos
- E. Cable USB 3.0

FRANÇAIS

- A. Boîtier en aluminium
- B. Circuit imprimé (PCB)
- C. Tournevis
- D. Vis
- E. Câble USB 3.0

繁體中文

- A. 鋁外殼
- B. 電路板 (PCB)
- C. 螺絲起子
- D. 螺絲
- E. USB 3.0線

ITALIANO


- A. Case di alluminio
- B. Printed circuit board (PCB)
- C. Saccia vite
- D. Viti
- E. Cavo USB 3.0

РУССКИЙ

- A. Алюминиевый корпус
- B. Печатная плата (PCB)
- C. Отвертка
- D. Винты
- E. USB 3.0 кабеля

簡體中文

- A. 鋁外殼
- B. 電路板 (PCB)
- C. 螺絲起子
- D. 螺絲
- E. USB 3.0線



ENGLISH

Connect hard drive to the PCB

DEUTSCH

Festplatte an die Platine anschließen

日本語

ハードディスクドライブをPCBに接続します

한국어

하드 드라이브를 PCB에 연결합니다

ESPAÑOL

Conecte el disco duro al PCB

FRANÇAIS

Connectez le disque dur au PCB

繁體中文

將硬碟與電路板 (PCB) 連接

ITALIANO


Collegare il disco rigido alla PCB

РУССКИЙ

Подключите жесткий диск к печатной плате

簡體中文

将硬盘与电路板 (PCB) 连接



ENGLISH

Slide the hard drive into the aluminium case

DEUTSCH

Festplatte in das Aluminiumgehäuse schieben

日本語

ハードディスクドライブをアルミニウム製ケースに装着します

한국어

하드 드라이브를 알루미늄 케이스에 밀어 넣습니다

ESPAÑOL

Deslice el disco duro en la carcasa de aluminio

FRANÇAIS

Glissez le disque dur dans le boîtier en aluminium

繁體中文

將硬碟滑入鋁外殼中

ITALIANO

Far scorrere il disco rigido nel case di alluminio

РУССКИЙ

Установите жесткий диск в алюминиевый корпус

簡體中文

将硬盘滑入铝外壳中



ENGLISH

Secure the cover with screws

DEUTSCH

Deckel mit Schrauben fixieren

日本語

ネジでカバーを固定します

한국어

나사로 커버를 고정합니다

ESPAÑOL

Fije la cubierta con tornillos

FRANÇAIS

Fixez le couvercle avec les vis

繁體中文

用螺絲固定外蓋

ITALIANO


Fissare il coperchio con le viti

РУССКИЙ

Закрепите крышку винтами

簡體中文

用螺丝固定外蓋



ENGLISH
1. Connect USB type A connector to the computer
2. Connect USB 3.0 micro-B connector to the enclosure

ESPAÑOL
1. Enchufe el conector USB tipo A al ordenador
2. Enchufe el conector USB 3.0 micro-B a la carcasa

ITALIANO
1. Collegare il connettore USB di tipo A al computer
2. Collegare il connettore USB 3.0 Micro-B al box

DEUTSCH
1. USB-A-Stecker an den Computer anschließen
2. Micro-USB 3.0 -B-Stecker an das Gehäuse anschließen

FRANÇAIS
1. Connectez le connecteur USB de type A à l'ordinateur
2. Connectez le connecteur micro-B USB 3.0 à l'accessoire

РУССКИЙ
1. Подключите разъем USB типа А к компьютеру
2. Подключите микроразъем USB 3.0 типа В к устройству

한국어

1. USB 타입 A 커넥터를 컴퓨터에 연결합니다
2. USB 3.0 마이크로 B 커넥터를 인클로저에 연결합니다

日本語
1. USB タイプAコネクタをコンピュータに接続します
2. USB 3.0マイクロBコネクタをエンクロージャーに接続します

繁體中文
1. 將USB type A型接頭與電腦連接
2. 將USB 3.0 micro-B型接頭與外接盒連接

簡體中文
1. 將USB type A型接頭與计算机連接
2. 將USB 3.0 micro-B型接頭與外接盒連接



ENGLISH
Installation complete

DEUTSCH
Die Installation ist damit abgeschlossen

ESPAÑOL
Instalación finalizada

FRANÇAIS
Installation terminée

ITALIANO
Installazione completata

РУССКИЙ
Сборка завершена

日本語
インストールは完了です
한국어
설치가 완료 되었습니다

繁體中文
安裝完成

簡體中文
安裝完成

Warranty Information

This product has a limited 1 year warranty in North America, and Australia. For information on warranty periods in other regions, please contact your reseller or SilverStone authorized distributor.

Warranty terms & conditions

1. Product component defects or damages resulted from defective production is covered under warranty. Defects or damages with the following conditions will be fixed or replaced under SilverStone Technology's jurisdiction.
 - a) Usage in accordance with instructions provided in this manual, with no misuse, overuse, or other inappropriate actions.
 - b) Damage not caused by natural disaster (thunder, fire, earthquake, flood, salt, wind, insect, animals, etc...)
 - c) Product is not disassembled, modified, or fixed. Components not disassembled or replaced.
 - d) Warranty mark/stickers are not removed or broken.
2. Loss or damages resulted from conditions other than ones listed above are not covered under warranty.
3. Under warranty, SilverStone Technology's maximum liability is limited to the current market value for the product (depreciated value, excluding shipping, handling, and other fees). SilverStone Technology is not responsible for other damages or loss associated with the use of product.
4. Under warranty, SilverStone Technology is obligated to repair or replace its defective products. Under no circumstances will SilverStone Technology be liable for damages in connection with the sale, purchase, or use including but not limited to loss of data, loss of business, loss of profits, loss of use of the product or incidental or consequential damage whether or not foreseeable and whether or not based on breach of warranty, contract or negligence, even if SilverStone Technology has been advised of the possibility of such damages.
5. Warranty covers only the original purchaser through authorized SilverStone distributors and resellers and is not transferable to a second hand purchaser.
6. You must provide sales receipt or invoice with clear indication of purchase date to determine warranty eligibility.
7. If a problem develops during the warranty period, please contact your retailer/reseller/SilverStone authorized distributors or SilverStone <http://www.silverstonetek.com>. Please note that: (i) You must provide proof of original purchase of the product by a dated itemized receipt; (ii) You shall bear the cost of shipping (or otherwise transporting) the product to SilverStone authorized distributors. SilverStone authorized distributors will bear the cost of shipping (or otherwise transporting) the product back to you after completing the warranty service; (iii) Before you send the product, you must be issued a Return Merchandise Authorization ("RMA") number from SilverStone. Updated warranty information will be posted on SilverStone's official website. Please visit <http://www.silverstonetek.com> for the latest updates.

Additional info & contacts

For North America (usasupport@silverstonetek.com) SilverStone Technology in North America may repair or replace defective product with refurbished product that is not new but has been functionally tested.

Replacement product will be warranted for remainder of the warranty period or thirty days, whichever is longer. All products should be sent back to the place of purchase if it is within 30 days of purchase, after 30 days, customers need to initiate RMA procedure with SilverStone Technology in USA by first downloading the "USA RMA form for end-users" form from the below link and follow its instructions.

<http://silverstonetek.com/contactus.php>

For Australia only (support@silverstonetek.com)

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.

You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Please refer to above "Warranty terms & conditions" for further warranty details.

SilverStone Technology Co., Ltd. 12F No. 168 Jiankang Rd., Zhonghe Dist., New Taipei City 235 Taipei R.O.C.

+ 886-2-8228-1238

(standard international call charges apply)

For Europe (support.eu@silverstonetek.de)

For all other regions (support@silverstonetek.com)